


RC-A6
遥控器
Remote Control
Fernsteuerung
使用手册
Instruction Manual



Godox
RC-A6

注: 此产品仅用于商业用途。

- LCD屏
- CH/GR按钮
- SET按钮
- +按钮
- 电池仓
- 电源开关
- 按钮
- 电池盖

使用说明

- 无线控制

RC-A6具有控制功能: 可以控制多组LED灯; 32个频道, 100个无线ID, 抗干扰能力强。

使用前请将LED灯的频道、组别和ID设置为与RC-A6遥控器相同。

2. 使用遥控器调整频道/组别

- 按CH/GR按钮, 组别图标闪烁。按“-”或“+”按钮选择组别, 可选范围: A-F, 0-9。
- 按CH/GR按钮两次, 频道图标闪烁。按“-”或“+”按钮选择频道, 可选范围: 1-32。

3. 使用遥控器调整 ID

- 短按两次CH/GR按钮, 短按“-”或“+”按钮选择ID号, 可选范围: OFF, 0-99。

4. 使用遥控器调节灯光亮度

- 短按“-”或“+”按钮调节灯光亮度。

5. 使用遥控器调节色温

- 短按遥控器SET按钮, 色温图标闪烁。同时按下“-”和“+”按钮可进行复位。注: 只有LED灯控制普通通信后能接收无线信号。

6. 遥控器复位

同时按下“-”和“+”按钮可进行复位。注: 只有LED灯控制普通通信后能接收无线信号。

产品信息

产品信息	型号	产品条码
用户信息	姓名	联系电话
	通信地址	
	名称	
	联系电话	
销售商信息	通信地址	
	销售日期	
备注		

注: 此表应由销售商盖章确认。

如何获得保修服务

您可直接与产品销售商或授权服务机构联系, 也可拨打神牛产品售后服务电话, 与我们联系。由我们的服务人员为您提供服务。申请保修时, 您需提供有效的保修卡作为保修凭证, 方可获得保修。如您不能提供有效的保修卡, 则在我们确认产品或部件属于保修范围的情况下, 也可以为您提供保修, 但这不作为我们的义务。

产品保修

尊敬的用户本保修卡是申请保修服务的重要凭证, 请您配合销售商填写并妥善保管, 谢谢!

如产品存在下列情况, 本文件项下的保证和服务将不通用: ①产品或部件超过相应保修期; ②错误或不适当使用, 维护或保管导致的故障或损坏, 如: 不当搬运; 非按产品合理预期用途使用, 不当拆接外置设备; 跌落或外力挤压; 接触或暴露于不当温度、溶剂、酸碱、水浸或潮湿环境; ③由非神牛授权机构或人员安装、修理、更改、添加或拆卸造成的故障或损坏; ④产品或部件原有识别信息被修改或更改或除去; ⑤无效保修卡; ⑥使用非合法授权、非标准或非公开发行的软件造成的故障或损坏; ⑦其他非因产品本身质量问题导致的故障或损坏。遇上述情况, 您应向相关责任方寻求解决, 神牛对此不承担任何责任。因非在保修期或保修范围内的部件、附件损坏导致产品不能正常使用的, 不是保修范围内的故障。产品使用过程中正常的磨损、磨损和消耗, 不是保修范围内的故障。

产品保修和服务支持信息

产品的保修期和服务类型按以下《产品保修信息》执行:

产品类型	通信名称	保修期(月)	保修服务类型
部件	主机	12	客户送修
	电池	3	客户送修
	充电器等带电性的部件	12	客户送修
其他	如闪光灯、造型灯、外壳、保护罩、包装等。	无	无保修

神牛产品售后服务电话: 0755-29609320-8062

Warning

This product is for commercial use. Operating frequency: 2412.99MHz - 2464.49MHz. Maximum Average EIRP Power: -10.32dBm.

Declaration of Conformity

GODOX Photo Equipment Co., Ltd. hereby declares that this Remote Control/RC-A6 is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. In accordance with Article 10(2) and Article 10(10), this product is allowed to be used in all EU member states. For more information of DoC, please click this web link: http://www.godox.com/DOC/Godox_RC-A6_DOC.pdf.

The device complies with RF specifications when the device used at 0mm from your body.

Operation

- Wireless Control**
RC-A6 has control function, and can control multiple groups of LED lights. The remote has 32 channels and 100 IDs to avoid interference. Please set the channels, groups and IDs of LED light to the same as those of RC-A6 remote control before usage.
- Adjusting Channel/Group with the Remote Control**
Press the CH/GR button and the group icon blinks.
Press the“-”/“+”button to choose a group (A to F to 9).
Press the CH/GR button twice and the channel icon blinks.
Press the“-”/“+”button to choose a channel (1 to 32).

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Warranty

Dear customers, as this warranty card is an important certificate to apply for our maintenance service, please fill in the following form in coordination with the seller and safe-keep it. Thank you!

Product Information	Model	Product Code Number
Customer Information	Name	Contact Number
	Address	
Seller Information	Name	Contact Number
	Address	
		Date of Sale
Note		

Note: This form shall be sealed by the seller.

Applicable Products

The document applies to the products listed on the Product Maintenance Information (see below for further information). Other products or accessories (e.g. promotional items, giveaways and additional accessories attached, etc.) are not included in this warranty scope.

Warranty Period

The warranty period of products and accessories is implemented according to the relevant Product Maintenance Information. The warranty period is calculated from the day (purchase date) when the product is bought for the first time. And the purchase date is considered as the date registered on the warranty card when buying the product.

How to Get the Maintenance Service

If maintenance service is needed, you can directly contact the product distributor or authorized service institutions. You can

also contact the Godox after-sale service call and we will offer you service. When applying for maintenance service, you should provide valid warranty card. If you cannot provide valid warranty card, we may offer you maintenance service once confirmed that the product or accessory is involved in the maintenance scope, but that shall not be considered as our obligation.

Inapplicable Cases

The guarantee and service offered by this document are not applicable in the following cases: ① The product or accessory has expired its warranty period; ② Breakage or damage caused by inappropriate usage, maintenance or preservation, such as improper packing, improper usage, improper plugging in/out external equipment, falling off or squeezing by external force, contacting or exposing to the improper temperature, solvent, acid, base, flooding and damp environments, etc.; ③ Breakage or damage caused by non-authorized institution or staff in the process of installation, maintenance, alternation, addition and detachment; ④ The original identifying information of product or accessory is modified, alternated, or removed; ⑤ No valid warranty card; ⑥ Breakage or damage caused by using illegally authorized, nonstandard or non-public released software; ⑦ Breakage or damage caused by force majeure or accident; ⑧ Breakage or damage that could not be attributed to the product itself. Once met these situations above, you should seek solutions from the related responsible parties and Godox assumes no responsibility. The damage caused by parts, accessories and software that beyond the warranty period or scope is not included in our maintenance scope. The normal

discoloration, abrasion and consumption are not the breakage within the maintenance scope.


Maintenance and Service Support Information

The warranty period and service types of products are implemented according to the following Product Maintenance Information:

Other Items	First-time handling cover/holding/expense, etc.	Parts	Name	Maintenance Period(month)	Warranty Service Type
		Electrical parts e. battery charger, etc.	Battery	12	Customer sends the product to designated site
		Circuit Board		3	Customer sends the product to designated site
				12	Customer sends the product to designated site
No	Without warranty				

Godox After-sale Service
Call: +86-755-29609320(8062)

Gehäuse



注: 此产品仅用于商业用途。

- LCD-Bildschirm
- Taste CH/GR
- Taste SET
- Batteriefach
- Netzschalter
- Taste -
- Batterieabdeckung

Warning

This product is for commercial use. Operating frequency: 2412.99MHz - 2464.49MHz. Maximum Average EIRP Power: -10.32dBm.

Declaration of Conformity

GODOX Photo Equipment Co., Ltd. hereby declares that this Remote Control/RC-A6 is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. In accordance with Article 10(2) and Article 10(10), this product is allowed to be used in all EU member states. For more information of DoC, please click this web link: http://www.godox.com/DOC/Godox_RC-A6_DOC.pdf.

The device complies with RF specifications when the device used at 0mm from your body.

Bedienungsanleitung

- Drahtlose Steuerung**
Der RC-A6 verfügt über eine Steuerfunktion, die mehrere LED-Lichter steuern kann. 32 Kanäle, 100 drahtlose ID, starke Anti-Interferenz-Fähigkeit. Vor dem Gebrauch stellen Sie bitte den Kanal, die Gruppe und die ID der LED-Lampe so ein, dass sie mit der RC-A6-Fernbedienung übereinstimmen.
- Verwenden Sie die Fernsteuerung, um Kanäle/Gruppen einzustellen**
Drücken Sie die Taste CH/GR, das Symbol der Gruppe blinkt.
Drücken Sie die Taste“-”/“+”, um die gewünschte Gruppe auszuwählen, wobei der Bereich der Optionen: A-F, 0-9.
Drücken Sie die Taste CH/GR zweimal, dann blinkt das Kanalsymbol.
Drücken Sie“-”/“+”, um den gewünschten Kanal von 1 bis 32 auszuwählen.

3. Verwenden Sie die Fernsteuerung, um die ID einzustellen

- Drücken Sie die Taste CH/GR zweimal und drücken Sie“-”/“+”, um die gewünschte ID auszuwählen. Optionaler Bereich: OFF, 0-99.

4. Verwenden Sie die Fernsteuerung, um die Helligkeit einzustellen

- Drücken Sie die Taste“-”/“+”, um die Helligkeit einzustellen.

5. Verwenden Sie die Fernsteuerung, um die Farbtemperatur einzustellen

- Drücken Sie die SET-Taste auf der Fernsteuerung, und das Symbol für die Farbtemperatur blinkt. Drücken Sie die Taste“-”/“+”.
- Stellen Sie die Farbtemperatur ein. (Die Farbtemperatur von SL200II und SL300II kann nicht eingestellt werden)

6. Zurücksetzen der Fernbedienung

- Drücken Sie gleichzeitig“-”/“+”, um das Gerät zurückzusetzen.

Spezifikationen

Modell	RC-A6
Die Stromversorgung	3(AA-Batterie *2)(batterie muss separat erworben werden)
Entfernung der Fernsteuerung	50m
Kanal	32
Gruppe	Gruppe 16(A-F, 0-9)
Standby-Zeit	Mehr als ein Jahr
Betriebstemperatur	-10°C ~ 50°C
Umgebung	
Größe	120*38*15mm
Das Nettogewicht	30g

Produktgarantie

Liebe Benutzer, diese Garantiekarte ist ein wichtiger Beweis für Garantie-Service zu beantragen, bitte kooperieren Sie mit dem Verkäufer auszufüllen und zu halten, danke!

Produktinformation	Modell	Produkt-Barcode
Benutzerinformation	Name	Kontakt Nummer
	Kontakt Adresse	
Anbieterinformationen	Name	Kontakt Nummer
	Kontakt Adresse	
	Verkaufdatum	

Bemerkung
Hinweis: Dieses Formular sollte vom Verkäufer versiegelt werden.

Anwendbare Produkte

Dieses Dokument gilt für Produkte, die in den entsprechenden Produktgarantieinformationen aufgeführt sind (siehe Anweisungen spielen) und andere Produkte oder Komponenten, die nicht Teil dieses Bereichs sind (z. B. Werkbeirat, Werbegeschenke und andere werksseitige Teile usw.), fallen nicht unter diese Garantiepflichtung.

Garantiezeitfrist

Die entsprechende Garantiezeit für Produkte und Komponenten basiert auf den entsprechenden Produktgarantieinformationen. Die Gewährleistungsfrist beginnt mit dem Datum des ersten Kaufs des Produkts, und das Datum des Kaufs ist das Datum der Registrierung der Garantiekarte zum Zeitpunkt des Kaufs.

Wie erhalten Sie einen Garantieservice

Um den Service zu garantieren, können Sie sich direkt an den Produktverkäufer oder die autorisierte Serviceagentur

wenden oder uns unter der Kundendienst-Telefonnummer der ShenNiü-Produkte anrufen, und unser Servicepersonal kann den Service für Sie arrangieren. Wenn Sie eine Garantie beantragen, sollten Sie eine gültige Garantiekarte als Garantienachweis vorlegen, falls Sie diese erhalten. Wenn Sie keine gültige Garantiekarte vorlegen können, können wir Ihnen auch eine Garantie gewähren, wenn wir bestätigen können, dass das Produkt oder Teil von der Garantie abgedeckt ist, aber dies ist nicht unsere Verpflichtung.

Umstände, bei denen die Garantie nicht gilt

Die Gewährleistungen und Dienstleistungen gemäß diesem Dokument gelten nicht ① das Produkt oder Teil überschreitet die entsprechende Garantiezeit, wenn das Produkt den folgenden Bedingungen unterliegt; ② Ausfall oder Beschädigung durch unsachgemäße oder unsachgemäße Verwendung, Wartung oder Verwahrung wie unsachgemäße Handhabung; Nicht zur Verwendung für den vernünftigerweise vorgesehenen Zweck des Produkts; Unsachgemäße Einstecken externer Geräte; Drop oder externe Kraftdrücken; Exposition gegenüber ungeeigneten Temperaturen, Lösungsmitteln, Säuren, Laugen, Überschwemmungen oder feuchten Umgebungen; ③ Ausfall oder Beschädigung durch Installation, Reparatur, Änderung, Ergänzung oder Entfernung durch eine nicht-ShenNiü autorisierte Stelle oder Person; ④ Die ursprünglichen Identifikationsinformationen des Produkts oder Teils werden geändert, geändert oder entfernt; ⑤ Keine gültige Garantiekarte; ⑥ Ausfall oder Beschädigung durch die Verwendung von Software, die nicht gesetzlich zulässig, nicht standardmäßig oder öffentlich vertrieben ist; ⑦ Ausfall oder Beschädigung durch höhere Gewalt oder Unfall; ⑧ Sonstige Ausfälle oder Schäden, die nicht durch Qualitätsprobleme mit dem Produkt selbst verursacht wurden. In den oben genannten Fällen sollten Sie eine

Lösung von der zuständigen Partei suchen, für die Shen Niü nicht verantwortlich ist. Wenn das Produkt aufgrund von Teilen, Zubehör oder Software, die nicht unter die Garantie oder Garantie fallen, nicht ordnungsgemäß funktioniert, ist es kein Fehler, der von der Garantie abgedeckt ist. Normale Verfärbung, Verschleiß und Verbrauch während der Verwendung des Produkts ist kein Fehler, der durch die Garantie abgedeckt wird.

Produktgarantie- und Service-Support-Informationen

Die Gewährleistungsfrist und die Art der Dienstleistung des Produkts erfolgen gemäß den folgenden Produktgarantieinformationen:

Sonstige	Produkttyp	Komponentenname	Garantiezeit (Monat)	Art der Dienstleistung
Keine	Komponente	Batterie	12	Kundenreparatur
Keine	Leiterplatte		3	Kundenreparatur
Keine	Leiterplatte		12	Kundenreparatur
Keine	Keine Garantie			Keine Garantie

Shen niu Produkte After-Sales-Service
Telefon 0755-29609320-8062

合格证
QC PASS

深圳市神牛摄影器材有限公司
地址: 深圳市宝安区福海街道塘尾社区
耀川工业区厂房2栋
电话: 0755-29609320(8062)
传真: 0755-25723423
邮箱: godox@godox.com

GODOX Photo Equipment Co., Ltd.
Add: Building 2, Yaocun Industrial Zone, Tangwei Community, Fuhai Street, Bao'an District, Shenzhen 518103, China
Tel: +86-755-29609320(8062)
Fax: +86-755-25723423
E-mail: godox@godox.com
godox.com Made in China